Implementation of 4x1 multiplexer and 1x4 demultiplexer using logic gates.

Theory

Introduction

The function of a multiplexer is to select the input of any 'n' input lines and feed that to one output line. The function of a de-multiplexer is to inverse the function of the multiplexer and the shortcut forms of the multiplexer. The de-multiplexers are mux and demux. Some multiplexers perform both multiplexing and de-multiplexing operations.




Figure-1:Block diagram of Multiplexer and De-multiplexer

1) Multiplexer

Multiplexer is a device that has multiple inputs and a single line output. The select lines determine which input is connected to the output, and also to increase the amount of data that can be sent over a network within certain time. It is also called a data selector.

Multiplexers are classified into four types:

- a) 2-1 multiplexer (1 select line)
- b) 4-1 multiplexer (2 select lines)
- c) 8-1 multiplexer(3 select lines)
- d) 16-1 multiplexer (4 select lines)

1.1) 4x1 Multiplexer

4x1 Multiplexer has four data inputs I3, I2, I1 & I0, two selection lines S1 & S0 and one output Y. The block diagram of 4x1 Multiplexer is shown in the following

figure. One of these 4 inputs will be connected to the output based on the combination of inputs present at these two selection lines. Truth table of 4x1 Multiplexer is shown below.




Figure-2:Block diagram of 4x1 Multiplexer

Selection Lines		Output	
s_1	S ₀	Υ	
0	0	I ₀	
0	1	I ₁	
1	0	I ₂	
1	1	I ₃	

Figure-3:Truth table of 4x1 Multiplexer

2) De-multiplexer

De-multiplexer is also a device with one input and multiple output lines. It is used to send a signal to one of the many devices. The main difference between a multiplexer and a de-multiplexer is that a multiplexer takes two or more signals and encodes them on a wire, whereas a de-multiplexer does reverse to what the multiplexer does.

De-multiplexer are classified into four types:

- a)1-2 demultiplexer (1 select line)
- b)1-4 demultiplexer (2 select lines)
- c)1-8 demultiplexer (3 select lines)
- d)1-16 demultiplexer (4 select lines)

2.2) 1x4 De-multiplexer

1x4 De-Multiplexer has one input I, two selection lines, S1 & S0 and four outputs Y3, Y2, Y1 & Y0. The block diagram of 1x4 De-Multiplexer is shown in the following figure.




Figure-4:Block diagram of 1x4 De-Multiplexer

Selection Inputs		Outputs			
s_1	s_0	Y 3	Υ2	Υ ₁	Υ ₀
0	0	0	0	0	I
0	1	0	0	I	0
1	0	0	I	0	0
1	1	I	0	0	0

Figure-5:Truth table of 1x4 De-Multiplexer